

# INSTALLATION INSTRUCTIONS

## DOORKIT END TRIM

STEP 1: Insert End Trim Hooks into Upright slots. Bottom of End Trim fits between Deck and Base End Trim or adjacent Deck as applicable. Top of trim will extend above upper Shelf.

STEP 2: Fasten the End Trim to the side of the Doorkit Frame as detailed below:

- Doorkits to 30" in height at two locations per side.
- Doorkits taller than 30" in height at three locations per side with locations equally spaced (See FIGURE 1).

- Using the inside center groove in the Doorkit Frame as a locator, drill a  $7/32$ " hole through the Frame and the End Trim, as close as possible to the upper corner of Doorkit Frame (See FIGURE 2).
- Attach the Trim to the Frame using #6-32 Screws and Binder Posts. (\*Screw and Binder Posts are in the Doorkit Hardware Pack).
- When LWS Top is used, drill a  $7/32$ " pilot hole through the End Trim only (locate the hole at centerline of thickness of LWS). Fasten with #8 x  $9/16$ " Pan Head screws provided (See FIGURE 3).

