

# INSTALLATION INSTRUCTIONS

## ACCESSORY PANEL CONNECTOR FOR FULL HEIGHT WING TO FULL HEIGHT MERCHANDISING PANEL

STEP 1: Install the bottom connector for the desired wing panel location and TEK screw it to the full height merchandising panel in two places. NOTE: For a standard wing application, align the two holes in the bottom connector with the two pilot holes in the bottom of the full height merchandising panel.

STEP 2: Install the full height merchandising panel (which now has the bottom connector installed).

STEP 3: Place the full height accessory (wing) panel into the bottom connector and install the top connector. TEK screw the top connector to the accessory panel and the merchandising panel in two places each. NOTE: For a standard wing application, align the two holes in the top connector with the two pilot holes in the top of the merchandising panel.

**MAXIMUM LOAD CAPACITY ON FULL HEIGHT ACCESSORY PANEL: 400 LBS.**

**MAXIMUM FULL HEIGHT ACCESSORY PANEL WIDTH: 36".**

**TO PROPERLY BALANCE THE FULL HEIGHT MERCHANDISING PANEL, THE LOAD ON THE FULL HEIGHT MERCHANDISING PANEL MUST BE EQUAL TO OR GREATER THAN THE LOAD ON THE FULL HEIGHT ACCESSORY PANEL.**

