

INSTALLATION INSTRUCTIONS

MOBILE UPRITE INSERT

Step 1: Install caster to mobile insert.

Step 2: Slide mobile uprite insert into bottom of uprite and attach.

Step 3: Assemble beams and shelf levels per standard widespan inst. instr. (01-60).

ADDITIONAL REQUIREMENTS:

- *Beams must be installed within 6" of bottom of posts.
- *All beams must have locking clips, WS1291 or beam lock WS9111, in place to prevent dislodging.
- *Upright height to depth shall not exceed 4:1.
- *No stock shall be higher than 84" above floor.

LOAD CAPACITY:

- *For single sections, maximum load:
 - 2,000 lbs (Static)
 - 840 lbs (Rolling)
- *For multiple sections, maximum load:
 - 1680 lbs (Static)
 - 420 lbs (Rolling) per uprite frame
- *Sample calculation for multiple sections:

$$\begin{array}{r} 1/2 \text{ section A} \\ + 1/2 \text{ section B} \\ \hline \end{array}$$

Total load on shared uprite frame

