

# INSTALLATION INSTRUCTIONS

## WALL END STABILIZER BRACKET

**STEP 1:** Fit stabilizer bracket into siderail lances of uprite & attach to wall end with tek screw. Pre-drill hole in top rail for tek screw.

NOTE: Tek screw may be installed in either available hole in bracket.



Bracket must be used with a height-to-base-compliant-wall end (see Inst Instr 01-13) and wall end must use base brackets.

