

INSTALLATION INSTRUCTIONS

ACCESSORY PANEL CONNECTOR FOR WING ON BASE END TRIM

STEP 1: Install Wall End Display according to installation instructions 01-13. Install upright hairpins, but DO NOT install WEDER, yet.

STEP 2: Install base angle by securing it to the flush accessory panel with two #10-32 self tapping screws (reference Figure 1).

STEP 3: Place the flush accessory panel with the installed base angle onto the base end trim. Then, install the top connector by aligning the top connector holes with pilot holes in the full height accessory panel and secure with two #10-32 tapping screws (reference Figure 2).

STEP 4: Install WEDER according to installation instructions 84235. The WEDER will saddle over the top connector. Align clearance hole #1 in the top connector before fastening the 1/4-20 machine screw into the upright insert (reference Figure 2).

MAXIMUM LOAD CAPACITY ON FLUSH ACCESSORY PANEL: 400 LBS.

MAXIMUM FLUSH ACCESSORY PANEL WIDTH: 36".

