



Wall End Display


- Free Standing End Display
- 2', 30", 3', 4' wide
- 48" - 96" high
- 13" - 25" deep

WED

No Base WED

No Base Wall End Display

- Attaches to Gondola
- No Base Deck on end
- 3', 4', 6' wide
- 72" - 120" high



End Displays

End Merchandising Panel & End Deck

- Attaches to Island Uprite
- 2', 30", 3', 4' wide
- 48" - 96" high

End Deck

- Matches overall Island width
- 06 or Low Base
- 13" - 25" deep
- Snaps on to Base End Trim
- Removable



CED



Contoured End Display

- Freestanding End Display
- Contour Deck & Shelves
- 2', 30", 3', 4' wide
- 48" - 96" high
- 13" - 25" deep