

| You are in: [Lozier](#) > [Products](#) > [Load Easer Base Bracket](#)

Load Easer Base Bracket

Part Number: **Part Number: LE**



Order the Load Easer Base Bracket to increase your Deck load capacity. Bracket is placed halfway between the Base Brackets and can be installed either straight or angled depending on the Base Deck depth.

Product Details:

- Use for additional Deck load capacity—Standard or Bullnose Deck
- Place Bracket halfway between Base Brackets either straight or angled depending on Base Deck depth
- Includes attached stabilizers
- Specify 06 Base or Low Base when ordering
- Evenly distributed load of 1,100 lbs/deck (13"D-19"D) and 1,300 lbs/deck (22"D-31"D)

Product Options and Numbers

Example Part #: **LE BB 06 PTD**

Load Easer: **LE**

Base Bracket: **BB**

Base Height: **06**, LB

Standard Finish: **PTD**, Optional **CHR**

Suffix Key	
06	- 06 Base (8"H)
LB	- Low Base (6"H)
PTD	- Painted Random
CHR	- Charcoal Black