


| You are in: [Lozier](#) > [Products](#) > [Pallet Rack Row Spacer](#)

Pallet Rack Row Spacer

Part Number: **LPRRS**



Product Details:

- Row Spacers are used to maintain proper spacing between back-to-back runs
- Required on all back-to-back runs that have height to depth ratio of 6:1 or greater
- Uprites up to 96" tall require 2 spacers per Uprite
- Uprites over 96" tall require 3 spacers per Uprite
- Hardware included

Product Options and Numbers

Example Part #: **LPRRS 2 QQ2**

Pallet Rack Row Spacer: **LPRRS**

Length: **2**, 3, 6, 8

Standard Finish: **QQ2**

Suffix Key	
2	- 2"Long

- 3** - 3" Long
- 6** - 6" Long
- 8** - 8" Long
- QQ2** - Gray